Accessories





AH04 (three-fuse kit) pictured here. AH02 contains only one fuse; AH03 contains two fuses.



HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Follow safe electrical work practices. See NFPA 70E in the USA, or applicable local code:
- This equipment must only be installed and serviced by qualified electrical personnel. Read, understand and follow the instructions before installing this product.
- Turn off all power supplying equipment before working on or inside the equipment.
- Use a properly rated voltage sensing device to confirm power is off.
- DO NOT DEPEND ON THIS PRODUCT FOR VOLTAGE INDICATION
- Only install this product on insulated conductors

Failure to follow these instructions will result in death or serious injury.

A qualified person is one who has skills and knowledge related to the construction and operation of this electrical equipment and the installation, and has received safety training to recognize and avoid the hazards involved.

NEC Article 100 No responsibility is assumed by Veris Industries for any consequences arising out of the use of this material.

NOTICE

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations
- The installer is responsible for conformance to all applicable codes Mount this product inside a suitable fire and electrical enclosure

AH02/03/04

1/2 Amp Fuse Packs for Applications to 600VAC

Specifications

Fuse	1/2 Amp 600VAC slow blow, 200kAlC, equivalent to Bussmann FNQ-R-1/2
Wire	14AWG, 18", 600VAC
Warranty	5 years

Installation

Disconnect power before installation.

- 1. Connect fuse to circuit as shown below. Fuse housing is labelled, showing which end must be connected to the
- 2. Fuses are replaceable. Use a 1/2 Amp 600 VAC slow blow Bussman or equivalent. To replace, unscrew the fuse housing in the center, remove used fuse, and insert new fuse, with the flat end of the fuse entering the Load side of the fuse housing. Screw the housing back together, and restore power.

Note: the fuse packs are supplied with hi-interrupt capability AC fuses installed in the fuse housings. These fuses are not rated for DC use.

