

NS Series Network Sensors Catalog Page

Description

The NS Series Network Sensor offering includes NS Series Network Zone Sensors and NS Series Network Discharge Air Sensors. The NS Series Network Sensors are designed to function directly with *Metasys*® system Field Equipment Controllers (FECs), Input/Output Modules (IOMs), VAV Modular Assembly (VMA16) Controllers, and Facility Explorer FX-PC Series Programmable Controllers (FX-PCGs, FX-PCVs, and FX-PCXs). The sensors are also compatible with Verasys™ and Johnson Controls Smart Equipment.

The majority of NS Series Network Zone Sensors monitor room temperature; however, options are available to also monitor zone humidity, carbon dioxide (CO₂), local temperature setpoint adjustments, and other variables. These data are transmitted to a controller on the Sensor Actuator (SA) Bus.

Some models of NS Series Network Zone Sensors include an onboard passive infrared (PIR) occupancy sensor that detects motion to determine if a space is occupied. This feature maximizes up to 30% energy savings in high-energy usage environments such as schools, dormitories, offices, hospitals, and hotels by adjusting the temperature of the space based on the occupancy status. In addition, the PIR occupancy sensor facilitates trending of floor space usage in these environments.

The NS Series Network Zone Sensors include models with either a temperature setpoint dial or setpoint pushbuttons and LCD that allows occupants to view the zone temperature, Relative Humidity (RH), and view and adjust the zone temperature setpoint. Some temperature and humidity models include an RH pushbutton to toggle between temperature and RH on the display. These models also have the capability to set the default display to either temperature or RH. Some models also include an °F/°C pushbutton to toggle between degrees Fahrenheit (F) and degrees Celsius (C).

A fan mode pushbutton is included to set the desired fan speed (AUTO-OFF-low-medium-high). An occupancy override function allows the user to signal to the controller that the zone is occupied to override the scheduled mode. Some models have DIP switches to set a unique address for applications that require multiple sensors.

For communication wiring flexibility, the wires connecting the network zone sensor to a controller can be terminated using a modular jack or screw terminals.

Note: Mixing of phone jack and screw terminal devices on the same SA bus segment must be avoided.

Each network sensor includes an SA Bus access port to allow accessories to access the SA Bus. This plug allows accessories to service or commission the connected controller or gain access to any other controller on the same Field Controller (FC) Bus.

The NS Series Network Zone Sensor offering includes models that can be surface mounted, vertical wallbox mounted, or flush mounted to meet the requirements of the specific application. Some NS Series Sensor models are designed to assist with the California Energy Code (Title 24). Select models offer stylish black enclosures to suit specific architectural and interior design needs.

The NS Series Network Discharge Air Sensors monitor the duct temperature, typically at the discharge of the VAV box, and transmit this data to a local controller on the SA Bus using the 10 ft (305 cm) wiring lead included with the unit. The 10 ft (305 cm) wiring lead consists of four 22 AWG (0.6 mm) trade-size, color-coded wires encased in a plenum-rated jacket. Each of the wires is stripped and tinned for easy connection to the SA Bus screw terminal block.

The NS Series Network Discharge Air Sensors are available with either a 4- or 8-in. (102 or 203 mm) temperature probe. All models include DIP switches for applications requiring multiple discharge air sensors, each with a unique DIP switch configurable address.

NS Series Network Sensors



Refer to the *NS Series Network Sensors Product Bulletin* (*LIT-12011574*) for important product application and single point of contact information.

Features

- BACnet® Master-Slave/Token-Passing (MS/TP) protocol communication—Provides compatibility with *Metasys* system field controllers and Facility Explorer programmable controllers in a proven communication network.
- Backlit LCD available on some models—Provides real-time status of the environment with backlighting activated during user interaction
- Simple temperature setpoint adjustment available on some models—Enables you to change the setpoint with the turn of a dial or press of a button.
- Onboard PIR occupancy sensor available on some models— Maximizes up to 30% energy savings in high-energy usage environments, and facilitates trending of floor space usage.
- Temporary occupancy available on some models—Provides a timed override command, which temporarily initiates an alternate mode.
- Field-selectable default display setting on some models—Allows you to toggle between temperature and RH on the display, and set the desired default for continuous viewing.
- Fahrenheit/Celsius (°F/°C) button available on some models— Toggles the display temperature between degrees Celsius and degrees Fahrenheit.

Note: Since some NS Series Network Sensor features are not supported in previous releases of *Metasys* or Facility Explorer system software, it is recommended that the system software be kept up to date.

Repair Information

If the NS Series Network Zone Sensor or the NS Series Network Discharge Air Sensor fails to operate within its specifications, replace the unit. For a replacement sensor, contact the nearest Johnson Controls® representative.



Selection Charts

Network Zone Sensor Ordering Information—Temperature Only Models (Part 1 of 2)

| Network Zone So | ensor Ord | ering Info | rmation— | Tempera | ture Only Mode | Is (Part 1 of 2 | 2) | | | | |
|---|------------------------------------|---|-----------------------------|----------------|---|---|--------------------------|-----------------|---|---------------------|-----------------------------|
| Product Code Number | Size (mm), Height x Width | Vertical Wallbox- Mounted (WB) or Surface- Mounted (SM) | Johnson Controls Logo | LCD Display | Temperature Adjustment: Setpoint Dial (Set), Warmer/ Cooler Dial (W/C), or Setpoint Push- buttons (PB) ¹ | Occupancy Override ² Button, PIR Occupancy Sensor | °F/°C Scale Toggle | Fan Control | Screw Terminals (ST) or Modular Jack (MJ) | Address Switches | VAV Balancing Feature |
| NS-ATA7001-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | No | MJ | No | No |
| NS-ATA7001-0A ³ | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | No | MJ | No | No |
| NS-ATA7002-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | No | ST | No | No |
| NS-ATA7002-0A ³ | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | No | ST | No | No |
| NS-ATA7002-3 ⁴ | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | No | ST | No | No |
| NS-ATA7003-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | No | ST | Yes | No |
| NS-ATA7004-2 | 80 x 80 | SM | No | Yes | Set | Yes, No | No | No | ST, MJ | Yes | No |
| NS-ATB7001-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | Yes | No | MJ | No | No |
| NS-ATB7002-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | Yes | No | ST | No | No |
| NS-ATB7003-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | Yes | No | ST | Yes | No |
| NS-ATC7001-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | Yes | MJ | No | No |
| NS-ATC7002-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | No | Yes | ST | No | No |
| NS-ATC7005-2 | 80 x 80 | SM | No | Yes | Set | Yes, No | No | Yes | ST, MJ | No | No |
| NS-ATD7001-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | Yes | Yes | MJ | No | No |
| NS-ATD7002-0 NS-ATF7001-0 | 80 x 80 80 x 80 | SM | Yes | Yes Yes | Set W/C | Yes, No Yes, No | Yes Yes | Yes No | ST MJ | No No | No No |
| NS-ATF7001-0 | 80 x 80 | SM | Yes | Yes | W/C | Yes, No | Yes | No | ST | No | No |
| NS-ATN7001-0 | 80 x 80 | SM | Yes | No | N/A | No, No | No | No | MJ | No | No |
| NS-ATN7001-2 | 80 x 80 | SM | No | No | N/A | No, No | No | No | MJ | No | No |
| NS-ATN7003-0 | 80 x 80 | SM | Yes | No | N/A | No, No | No | No | ST | Yes | No |
| NS-ATN7003-2 | 80 x 80 | SM | No | No | N/A | No, No | No | No | ST | Yes | No |
| NS-ATN7004-2 | 80 x 80 | SM | No | No | N/A | No, No | No | No | ST, MJ | Yes | No |
| NS-ATP7001-0 | 80 x 80 | SM | Yes | No | W/C | Yes, No | No | No | MJ | No | No |
| NS-ATP7001-2 | 80 x 80 | SM | No | No | W/C | Yes, No | No | No | MJ | No | No |
| NS-ATP7002-0 | 80 x 80 | SM | Yes | No | W/C | Yes, No | No | No | ST | No | No |
| NS-ATP7002-2 | 80 x 80 | SM | No | No | W/C | Yes, No | No | No | ST | No | No |
| NS-ATP7003-0 | 80 x 80 | SM | Yes | No | W/C | Yes, No | No | No | ST | Yes | No |
| NS-ATP7003-2 | 80 x 80 | SM | No | No | W/C | Yes, No | No | No | ST | Yes | No |
| NS-ATV7001-0 | 80 x 80 | SM | Yes | Yes | Set | Yes, No | Yes | No ⁵ | MJ | No | Yes |
| NS-ATV7002-0 NS-BTB7001-0 | 80 x 80 120 x 80 | SM WB, SM | Yes | Yes | Set | Yes, No | Yes | No ⁵ | ST MJ | No No | Yes |
| NS-BTB7001-0 | 120 x 80 | WB, SM | Yes No | Yes Yes | Set Set | Yes, No Yes, No | Yes Yes | No No | MJ | No | No No |
| | 120 x 80 | WB, SM | Yes | Yes | Set | Yes. No | Yes | No | MJ | No | No |
| NS-BTB7001-3 ⁴ NS-BTB7002-0 | 120 x 80 | WB, SM | Yes | Yes | Set | Yes, No | Yes | No | ST | No | No |
| NS-BTB7002-0 | 120 x 80 | WB, SM | Yes | Yes | Set | Yes, No | Yes | No | ST | Yes | No |
| NS-BTB7003-2 | 120 x 80 | WB, SM | No | Yes | Set | Yes, No | Yes | No | ST | Yes | No |
| NS-BTF7001-0 | 120 x 80 | WB, SM | Yes | Yes | W/C | Yes, No | Yes | No | MJ | No | No |
| NS-BTF7002-0 | 120 x 80 | WB, SM | Yes | Yes | W/C | Yes, No | Yes | No | ST | No | No |
| NS-BTJ7001-0 | 120 x 80 | WB, SM | Yes | Yes | РВ | Yes, No | Yes | No | MJ | No | No |
| NS-BTJ7001-2 | 120 x 80 | WB, SM | No | Yes | PB | Yes, No | Yes | No | MJ | No | No |
| NS-BTJ7002-0 | 120 x 80 | WB, SM | Yes | Yes | РВ | Yes, No | Yes | No | ST | No | No |
| NS-BTJ7002-2 | 120 x 80 | WB, SM | No | Yes | РВ | Yes, No | Yes | No | ST | No | No |
| NS-BTJ7003-0 | 120 x 80 | WB, SM | Yes | Yes | PB | Yes, No | Yes | No | ST | Yes | No |
| NS-BTJ7003-2 | 120 x 80 | WB, SM | No | Yes | PB | Yes, No | Yes | No | ST | Yes | No |
| NS-BTK7001-0 | 120 x 80 | WB, SM | Yes | Yes | PB | Yes, No | Yes | Yes | MJ | No | No |
| NS-BTK7001-2 | 120 x 80 | WB, SM | No | Yes | PB | Yes, No | Yes | Yes | MJ | No | No |
| NS-BTK7002-0 | 120 x 80 | WB, SM | Yes | Yes | PB | Yes, No | Yes | Yes | ST | No | No |
| NS-BTK7002-2 | 120 x 80 | WB, SM | No | Yes | PB N/A | Yes, No | Yes | Yes | ST | No | No |
| NS-BTL7003-0 NS-BTN7001-0 | 120 x 80 120 x 80 | WB, SM WB, SM | Yes Yes | No No | N/A N/A | Yes, No No, No | No No | No No | ST MJ | Yes No | No No |
| 149-D114/001-0 | 12U X 0U | VVD, SIVI | 162 | INU | IV/A | INO, INO | INU | INO | IVIJ | INU | INU |



Network Zone Sensor Ordering Information—Temperature Only Models (Part 2 of 2)

| Product Code Number | Size (mm), Height x Width | Vertical Wallbox- Mounted (WB) or Surface- Mounted (SM) | Johnson Controls Logo | | Temperature Adjustment: Setpoint Dial (Set), Warmer/ Cooler Dial (W/C), or Setpoint Push- buttons (PB) ¹ | Occupancy Override ² Button, PIR Occupancy Sensor | °F/°C Scale Toggle | Fan Control | Screw Terminals (ST) or Modular Jack (MJ) | Address Switches | VAV Balancing Feature |
|------------------------|------------------------------------|---|-----------------------------|-----|---|---|--------------------------|-----------------|---|---------------------|-----------------------------|
| NS-BTN7001-2 | 120 x 80 | WB, SM | No | No | N/A | No, No | No | No | MJ | No | No |
| NS-BTN7003-0 | 120 x 80 | WB, SM | Yes | No | N/A | No, No | No | No | ST | Yes | No |
| NS-BTN7003-2 | 120 x 80 | WB, SM | No | No | N/A | No, No | No | No | ST | Yes | No |
| NS-BTP7001-0 | 120 x 80 | WB, SM | Yes | No | W/C | Yes, No | No | No | MJ | No | No |
| NS-BTP7001-2 | 120 x 80 | WB, SM | No | No | W/C | Yes, No | No | No | MJ | No | No |
| NS-BTP7002-0 | 120 x 80 | WB, SM | Yes | No | W/C | Yes, No | No | No | ST | No | No |
| NS-BTP7002-2 | 120 x 80 | WB, SM | No | No | W/C | Yes, No | No | No | ST | No | No |
| NS-BTP7003-0 | 120 x 80 | WB, SM | Yes | No | W/C | Yes, No | No | No | ST | Yes | No |
| NS-BTV7001-0 | 120 x 80 | WB, SM | Yes | Yes | Set | Yes, No | Yes | No ⁵ | MJ | No | Yes |
| NS-BTV7002-0 | 120 x 80 | WB, SM | Yes | Yes | Set | Yes, No | Yes | No ⁵ | ST | No | Yes |
| NS-MTB7001-0 | 120 x 80 | WB, SM | Yes | Yes | Set | Yes, Yes | Yes | No | MJ | No | No |
| NS-MTB7002-0 | 120 x 80 | WB, SM | Yes | Yes | Set | Yes, Yes | Yes | No | ST | No | No |
| NS-MTB7004-2 | 120 x 80 | WB, SM | No | Yes | Set | Yes, Yes | Yes | No | ST, MJ | Yes | No |
| NS-MTJ7001-0 | 120 x 80 | WB, SM | Yes | Yes | PB | Yes, Yes | Yes | No | MJ | No | No |
| NS-MTJ7001-2 | 120 x 80 | WB, SM | No | Yes | РВ | Yes, Yes | Yes | No | MJ | No | No |
| NS-MTJ7002-0 | 120 x 80 | WB, SM | Yes | Yes | РВ | Yes, Yes | Yes | No | ST | No | No |
| NS-MTJ7002-2 | 120 x 80 | WB, SM | No | Yes | РВ | Yes, Yes | Yes | No | ST | No | No |
| NS-MTL7001-0 | 120 x 80 | WB, SM | Yes | No | N/A | Yes, Yes | No | No | MJ | No | No |
| NS-MTL7002-0 | 120 x 80 | WB, SM | Yes | No | N/A | Yes, Yes | No | No | ST | No | No |
| NS-MTN7004-2 | 120 x 80 | WB, SM | No | No | N/A | No, Yes | No | No | ST, MJ | Yes | No |

- 1. Use the setpoint dial or pushbuttons to adjust the absolute temperature setpoint.
- 2. An Occupancy Override button is available on NS-xxP and NS-xxL models. Other models allow Occupancy Override through the setpoint adjustment interface.
- 3. This model is currently only available in Asia. Contact your Johnson Controls representative for more information.
- 4. These models feature a black enclosure.
- 5. In the VAV balancing models, the fan control button is replaced by a light bulb button used in the VAV balancing process.

Network Zone Sensor Ordering Information—Temperature and Humidity Models without RH Display (Part 1 of 2)

| Product Code Number | Size (mm), Height x Width | Vertical Wallbox- Mounted (WB) or Surface- Mounted (SM) | Johnson Controls Logo | LCD Dis- play, RH Display | Humidity Element Accuracy | Temperature Adjustment: Setpoint Dial (Set) or Warmer/Cooler Dial (W/C) | Occupancy Override ¹ But- ton, PIR Occupancy Sensor | °F/°C Scale Toggle | Screw Terminals (ST) or Mod- ular Jack (MJ) | Address Switches |
|------------------------|------------------------------------|---|-----------------------------|---------------------------------|---------------------------------|---|---|--------------------------|---|---------------------|
| NS-AHA7001-0 | 80 x 80 | SM | Yes | Yes, No | 3% | Set | Yes, No | No | MJ | No |
| NS-AHA7002-0 | 80 x 80 | SM | Yes | Yes, No | 3% | Set | Yes, No | No | ST | No |
| NS-AHA7004-2 | 80 x 80 | SM | No | Yes, No | 3% | Set | Yes, No | No | ST, MJ | Yes |
| NS-AHB7001-0 | 80 x 80 | SM | Yes | Yes, No | 3% | Set | Yes, No | Yes | MJ | No |
| NS-AHB7002-0 | 80 x 80 | SM | Yes | Yes, No | 3% | Set | Yes, No | Yes | ST | No |
| NS-AHB7003-0 | 80 x 80 | SM | Yes | Yes, No | 3% | Set | Yes, No | Yes | ST | Yes |
| NS-AHN7001-0 | 80 x 80 | SM | Yes | None | 3% | N/A | No, No | No | MJ | No |
| NS-AHN7001-2 | 80 x 80 | SM | No | None | 3% | N/A | No, No | No | MJ | No |
| NS-AHN7003-0 | 80 x 80 | SM | Yes | None | 3% | N/A | No, No | No | ST | Yes |
| NS-AHN7004-2 | 80 x 80 | SM | No | None | 3% | N/A | No, No | No | ST, MJ | Yes |
| NS-AHP7001-0 | 80 x 80 | SM | Yes | None | 3% | W/C | Yes, No | No | MJ | No |
| NS-APA7001-0 | 80 x 80 | SM | Yes | Yes, No | 2% | Set | Yes, No | No | MJ | No |
| NS-APA7002-0 | 80 x 80 | SM | Yes | Yes, No | 2% | Set | Yes, No | No | ST | No |
| NS-APB7001-0 | 80 x 80 | SM | Yes | Yes, No | 2% | Set | Yes, No | Yes | MJ | No |
| NS-APB7002-0 | 80 x 80 | SM | Yes | Yes, No | 2% | Set | Yes, No | Yes | ST | No |
| NS-APB7003-0 | 80 x 80 | SM | Yes | Yes, No | 2% | Set | Yes, No | Yes | ST | Yes |
| NS-BHB7001-0 | 120 x 80 | WB, SM | Yes | Yes, No | 3% | Set | Yes, No | Yes | MJ | No |
| NS-BHB7002-0 | 120 x 80 | WB, SM | Yes | Yes, No | 3% | Set | Yes, No | Yes | ST | No |
| NS-BHB7003-0 | 120 x 80 | WB, SM | Yes | Yes, No | 3% | Set | Yes, No | Yes | ST | Yes |
| NS-BHN7001-0 | 120 x 80 | WB, SM | Yes | None | 3% | N/A | No, No | No | MJ | No |
| NS-BHN7001-2 | 120 x 80 | WB, SM | No | None | 3% | N/A | No, No | No | MJ | No |
| NS-BHN7003-0 | 120 x 80 | WB, SM | Yes | None | 3% | N/A | No, No | No | ST | Yes |



Network Zone Sensor Ordering Information—Temperature and Humidity Models without RH Display (Part 2 of 2)

| Product Code Number | Size (mm), Height x Width | Vertical Wallbox- Mounted (WB) or Surface- Mounted (SM) | Johnson Controls Logo | LCD Dis- play, RH Display | Humidity Element Accuracy | Temperature Adjustment: Setpoint Dial (Set) or Warmer/Cooler Dial (W/C) | Occupancy Override ¹ But- ton, PIR Occupancy Sensor | °F/°C Scale Toggle | Screw Terminals (ST) or Mod- ular Jack (MJ) | Address Switches |
|------------------------|------------------------------------|---|-----------------------------|---------------------------------|---------------------------------|--|---|--------------------------|---|---------------------|
| NS-BHP7001-0 | 120 x 80 | WB, SM | Yes | None | 3% | W/C | Yes, No | No | MJ | No |
| NS-BHP7003-0 | 120 x 80 | WB, SM | Yes | None | 3% | W/C | Yes, No | No | ST | Yes |
| NS-BPB7001-0 | 120 x 80 | WB, SM | Yes | Yes, No | 2% | Set | Yes, No | Yes | MJ | No |
| NS-BPB7002-0 | 120 x 80 | WB, SM | Yes | Yes, No | 2% | Set | Yes, No | Yes | ST | No |
| NS-BPB7003-0 | 120 x 80 | WB, SM | Yes | Yes, No | 2% | Set | Yes, No | Yes | ST | Yes |
| NS-MHB7004-2 | 120 x 80 | WB, SM | No | Yes, No | 3% | Set | Yes, Yes | Yes | ST, MJ | Yes |
| NS-MHL7001-0 | 120 x 80 | WB, SM | Yes | No, No | 3% | N/A | Yes, Yes | No | MJ | No |
| NS-MHL7002-0 | 120 x 80 | WB, SM | Yes | No, No | 3% | N/A | Yes, Yes | No | ST | No |
| NS-MHN7004-2 | 120 x 80 | WB, SM | No | None | 3% | N/A | No, Yes | No | ST, MJ | Yes |

^{1.} An Occupancy Override button is available on NS-xxP and NS-xxL models. Other models allow Occupancy Override through the setpoint adjustment interface.

Network Zone Sensor Ordering Information—Temperature and Humidity Models with Temperature or RH Display (Field-Selectable Default Display)

| Product Code Number | Size (mm), Height x Width | Vertical Wallbox- Mounted (WB) or Surface- Mounted (SM) | Johnson Controls Logo | LCD Display, RH Display | Humidity Element Accuracy | Temperature Adjustment: Setpoint Dial (Set) or Setpoint Pushbuttons (PB) ¹ | Occupancy Override ² | °F/°C Scale Toggle | Screw Terminals (ST) or Modular Jack (MJ) | Address Switches |
|---------------------------|---------------------------------|--|-----------------------------|----------------------------------|---------------------------------|---|------------------------------------|--------------------------|--|---------------------|
| NS-AHR7101-0 | 80 x 80 | SM | Yes | Yes, Yes | 3% | Set | Yes | Yes | MJ | No |
| NS-AHR7102-0 | 80 x 80 | SM | Yes | Yes, Yes | 3% | Set | Yes | Yes | ST | No |
| NS-AHR7103-0 | 80 x 80 | SM | Yes | Yes, Yes | 3% | Set | Yes | Yes | ST | Yes |
| NS-APR7101-0 | 80 x 80 | SM | Yes | Yes, Yes | 2% | Set | Yes | Yes | MJ | No |
| NS-APR7102-0 | 80 x 80 | SM | Yes | Yes, Yes | 2% | Set | Yes | Yes | ST | No |
| NS-BHM7101-0 | 120 x 80 | WB, SM | Yes | Yes, Yes | 3% | PB | Yes | Yes | MJ | No |
| NS-BHM7101-2 | 120 x 80 | WB, SM | No | Yes, Yes | 3% | PB | Yes | Yes | MJ | No |
| NS-BHM7102-0 | 120 x 80 | WB, SM | Yes | Yes, Yes | 3% | PB | Yes | Yes | ST | No |
| NS-BHM7102-2 | 120 x 80 | WB, SM | No | Yes, Yes | 3% | РВ | Yes | Yes | ST | No |
| NS-BHM7103-0 | 120 x 80 | WB, SM | Yes | Yes, Yes | 3% | PB | Yes | Yes | ST | Yes |
| NS-BHM7103-2 | 120 x 80 | WB, SM | No | Yes, Yes | 3% | PB | Yes | Yes | ST | Yes |
| NS-BHR7101-0 | 120 x 80 | WB, SM | Yes | Yes, Yes | 3% | Set | Yes | Yes | MJ | No |
| NS-BHR7103-0 | 120 x 80 | WB, SM | Yes | Yes, Yes | 3% | Set | Yes | Yes | ST | Yes |

^{1.} Use the setpoint dial or pushbuttons to adjust the absolute temperature setpoint.

Network Zone Sensor Ordering Information—Motion Detection Only Models (No Temperature or Humidity Sensing)

| Network Zone Senso | | | | | _ | , ,, | |
|--------------------|----------------|---|---------|---------|---------------|--|----------|
| Product | Size (mm), | Vertical Wallbox- | Johnson | LCD | PIR Occupancy | Screw | Address |
| Code Number | Height x Width | Mounted (WB), or Surface-Mounted (SM) | | Display | Sensor | Terminals (ST), or Modular Jack (MJ) | Switches |
| NS-MNN7001-0 | 120 x 80 | WB, SM | Yes | No | Yes | MJ | No |
| NS-MNN7003-0 | 120 x 80 | WB, SM | Yes | No | Yes | ST | Yes |
| NS-MNN7004-2 | 120 x 80 | WB, SM | No | No | Yes | ST, MJ | Yes |

Network Zone Sensor Ordering Information—CO₂ Models

| | • | Vertical Wallbox- Mounted (WB), or Surface-Mounted (SM) | | CO ₂ Measurement Range | Controls | Screw Terminals (ST), or Modular Jack (MJ) | Sensor Addressing |
|--------------|----------|--|----|--------------------------------------|----------|---|----------------------------|
| NS-BCN7004-0 | 120 x 80 | WB, SM | No | 0 to 2,000 ppm | Yes | ST, MJ | DIP Switch (212 to 219) |
| NS-BCN7004-2 | 120 x 80 | WB, SM | No | 0 to 2,000 ppm | No | ST, MJ | DIP Switch (212 to 219) |

^{2.} An Occupancy Override button is available on NS-xxP and NS-xxL models. Other models allow Occupancy Override through the setpoint adjustment interface.



Network Zone Sensor Ordering Information—Flush-Mount Temperature Only Models

| Product Code Number | | Mounting | | Measurement | Johnson Controls Logo | Sensor Addressing |
|------------------------|---|-------------|----|-----------------------------------|-----------------------------|----------------------------|
| | 4-1/2 in. x 2-3/4 in. (114 mm x 70 mm) | Flush-Mount | - | 32.0°F/0.0°C to 104.0°F/40.0°C | Yes | DIP Switch (200 to 203) |
| | 4-1/2 in. x 2-3/4 in. (114 mm x 70 mm) | Flush-Mount | No | 32.0°F/0.0°C to 104.0°F/40.0°C | No | DIP Switch (200 to 203) |

Network Discharge Air Sensor Ordering Information

| Product Code Number | Dimensions, Height x Width x Depth | Johnson Controls Logo | Temperature Probe Length | 10 ft (305 cm) Wiring Lead Included | Terminations | Sensor Addressing |
|------------------------|--|-----------------------------|-----------------------------|---|----------------------|----------------------------|
| NS-DTN7043-0 | 3 in. x 3 in. x 2 in. (76 mm x 76 mm x 51 mm) | Yes | 4 in. (102 mm) | Yes | Screw Terminal Block | DIP Switch (204 to 211) |
| NS-DTN7043-2 | 3 in. x 3 in. x 2 in. (76 mm x 76 mm x 51 mm) | No | 4 in. (102 mm) | Yes | Screw Terminal Block | DIP Switch (204 to 211) |
| NS-DTN7083-0 | 3 in. x 3 in. x 2 in. (76 mm x 76 mm x 51 mm) | Yes | 8 in. (203 mm) | Yes | Screw Terminal Block | DIP Switch (204 to 211) |
| NS-DTN7083-2 | 3 in. x 3 in. x 2 in. (76 mm x 76 mm x 51 mm) | No | 8 in. (203 mm) | Yes | Screw Terminal Block | DIP Switch (204 to 211) |

Network Sensors with Fault Code Capability Ordering Information (Title 24 Models for Economizer Fault Detection Diagnostics

| [FDD]) |
|--------|
|--------|

| Product Code Number | Size (mm), Height x Width | Vertical Wallbox- Mounted (WB) | LCD Display, °F/°C Scale Toggle | Screw Terminals | Address Switches | Temperature Adjustment: Setpoint (Set) or Warmer/ Cooler Dial (W/C) | Johnson Controls Logo | VAV Balancing Feature |
|------------------------|------------------------------|---|---------------------------------------|--------------------|---------------------|---|-----------------------------|--------------------------|
| NS-ATB7F03-0 | 80 x 80 | Yes | Yes, Yes | Yes | Yes | Set | Yes | No |
| NS-ATB7F03-1 | 80 x 80 | Yes | Yes, Yes | Yes | Yes | Set | No | No |
| NS-BTB7F03-0 | 80 x 120 | Yes | Yes, Yes | Yes | Yes | Set | Yes | No |
| NS-BTB7F03-1 | 80 x 120 | Yes | Yes, Yes | Yes | Yes | Set | No | No |

NS Sensors with Fault Code Capability Error Codes

The fault indication comes through the Network Sensor Bus when a Network Sensor is used in the Zone. The LCD indicates the code number for all the required state of California Title 24 economizer fault conditions.

| Display Text | California Title 24 Economizer Fault Condition | Possible Problem |
|--------------|--|--|
| EF1 | Air temperature sensor failure/fault | Problem with one of the air temperature sensors. Check Outdoor Air, Return Air, or Supply Air sensors. |
| EF5 | Not economizing when it should | The economizer is not using outdoor air when it should. |
| EF6 | Economizing when it should | The economizer is allowing outdoor air inside when the conditions are not suitable for economizer operation. |
| EF8 | Damper not modulating | The economizer damper is not able to modulate properly. Check damper, linkage to actuator, or the actuator. |
| EF9 | Excess outdoor air | The economizer is allowing excess outdoor air inside. |



Technical Specifications

| reominear op | | Zone Sensors—Temperature Only Models and Temperature and Humidity Models |
|--|---------------------------------------|---|
| Supply Voltage | | 9.8 to 16.5 VDC; 15 VDC nominal (from SA bus) |
| Current Consumption | | Temperature only models with LCD display: 21 mA maximum (non-transmitting) |
| | | Temperature only models without LCD display: 13 mA maximum (non-transmitting) |
| | | Temperature and humidity models with LCD display: 25 mA maximum |
| | | (non-transmitting) |
| | | Temperature and humidity models without LCD display: 17 mA maximum |
| Torminations | | (non-transmitting) |
| Terminations | | Modular jack or screw terminal block NS-AHx7x0x-x, NS-AHx7003-0, NS-APx7x0x-0, NS-APB7003-0, NS-ATx7003-0, NS-ATB7F03-x, NS-BCN7004-x, |
| Sensor Addressing | | NS-BHx7x0x-0, NS-BHx7003-0, NS-BPx700x-0, NS-BPB7003-0, NS-BTB7F03-x, NS-BTN7003-0, NS-BTN7003-0, and NS-BTP7003-0 Models: DIP switch set from 200 to 203; factory set at 203 |
| | | All other models: Fixed address of 199 |
| Wire Size | | Modular jack models: 24 AWG or 26 AWG (0.5 or 0.4 mm diameter) recommended; three twisted pair (six conductors) |
| | | Screw terminal block models: 18 to 22 AWG (1.0 to 0.6 mm diameter); 22 AWG (0.6 mm diameter) recommended |
| Communication R | ate | Auto-detect: 9.6k, 19.2k, 38.4k, or 76.8k bps |
| Mounting | | Surface-mounted: 80 x 80 mm |
| | | Surface-mounted or vertical wallbox-mounted: 120 x 80 mm |
| Temperature Meas | urement Range | 32.0°F/0.0°C to 104.0°F/40.0°C |
| Humidity Measure | ment Range | Full range: 0 to 100% RH |
| | | Calibrated range: 10 to 90% RH |
| Temperature Sens | or Type | Local 1k ohm Platinum Resistance Temperature Detector (RTD); Class A per IEC 60751 |
| Humidity Sensor T | • • | Thin film capacitive sensor |
| Temperature Reso LCD) | lution (Models with | ±0.5F°/±0.5C° |
| Temperature Accu | racy | NS Series Network Zone Sensor: ±1.0F°/±0.6C° |
| | | Temperature element only: 0.35F° at 70°F (0.2C° at 21°C) |
| Humidity Element | Accuracy | NS-APx700x-0 and NS-BPB700x-0 models: ±2% RH for 20 to 80% RH; ±4% RH for 10 to 20% and 80 to 90% RH |
| | | NS-AHx700x-x, NS-BHx700x-0, and NS-MHx700x-x models: ±3% RH for 20 to 80% RH; ±6% RH for 10 to 20% and 80 to 90% RH |
| Time Constant | | 10 minutes nominal at 10 fpm airflow |
| Default Temperatu | | With LCD display: 50.0°F/10.0°C to 86.0°F/30.0°C in 0.5° increments |
| Adjustment Range | • | Without LCD display: ±5.0F°/±3.0C° |
| PIR Occupancy Se Motion Detection (| Models with | Minimum 94 angular degrees up to a distance of 15 ft (4.6 m); based on a clear line of sight |
| PIR Occupancy Se | | |
| Ambient Condition | ıs | Operating: 32 to 104°F (0 to 40°C); 10 to 90% RH, noncondensing; 85°F (29°C) maximum dew point |
| | | Storage with LCD display: -4 to 140°F (-20 to 60°C); 5 to 95% RH, noncondensing |
| 0 | DAC: | Storage without LCD display: -40 to 158°F (-40 to 70°C); 5 to 95% RH, noncondensing |
| Compliance | BACnet International | BACnet Testing Laboratories™ (BTL) 135-2004 Listed BACnet Smart Sensor (B-SS) Note: Excludes the NS-ATV700x-0 and NS-BTV700x-0 models. |
| | United States | UL Listed, File E107041, CCN PAZX, Under UL 916, Energy Management Equipment; |
| | | FCC Compliant to CFR 47, Part 15, Subpart B, Class A |
| | | Note: Excludes the NS-ATA7001-0A and NS-ATA7002-0A models (Asia Only) |
| | Canada | UL Listed, File E107041, CCN PAZX7, Under CAN/CSA C22.2 No. 205, Signal Equipment; |
| | | Industry Canada, ICES-003 Note: Excludes the NS-ATA7001-0A and NS-ATA7002-0A models (Asia Only) |
| | Europe | CE Mark – Johnson Controls declares that this product is in compliance with the essential requirements and other |
| CE | Luiope | relevant provisions of the EMC Directive 2004/108/EC. |
| | Australia and New Zealand | RCM Mark, Australia/NZ Emissions Compliant |
| Accessory (Order | Separately) | NS-WALLPLATE-0: adapts an 80 x 80 mm NS Series Network Zone Sensor to a standard 80 x 120 mm wallbox |
| Shipping Weight | · · · · · · · · · · · · · · · · · · · | 0.20 lb (0.09 kg) |
| Shipping Weight | | |

| NS Series Network Zone Sensors—Motion Detection Only Models (No Temperature or Humidity Sensing) (Part 1 of 2) | | |
|--|--|--|
| Supply Voltage | 9.8 to 16.5 VDC; 15 VDC nominal (from SA bus) | |
| Current Consumption | 13 mA maximum (non-transmitting) | |
| Terminations | Modular jack or screw terminal block | |
| Sensor Addressing (NS-MNN7003-0 Model) | DIP switch set from 200 to 203; factory set at 203 | |



| Wire Size Communication Rate | | Modular jack model: 24 AWG or 26 AWG (0.5 or 0.4 mm diameter) recommended; three twisted pair (six conductors) |
|--|------------------------------|--|
| | | Screw terminal block model: 18 to 22 AWG (1.0 to 0.6 mm diameter); 22 AWG (0.6 mm diameter) recommended |
| | | Auto-detect: 9.6k, 19.2k, 38.4k, or 76.8k bps |
| Mounting | | Surface-mounted or vertical wallbox-mounted: 120 x 80 mm |
| PIR Occupancy Sensor Motion Detection | | Minimum 94 angular degrees up to a distance of 15 ft (4.6 m); based on a clear line of sight |
| Ambient Condition | ons | Operating: 32 to 104°F (0 to 40°C); 10 to 90% RH, noncondensing; 85°F (29°C) maximum dew point |
| | | Storage: -40 to 158°F (-40 to 70°C); 5 to 95% RH, noncondensing |
| Compliance | BACnet International | BACnet Testing Laboratories™ (BTL) 135-2004 Listed BACnet Smart Sensor (B-SS) |
| | United States | UL Listed, File E107041, CCN PAZX, Under UL 916, Energy Management Equipment; FCC Compliant to CFR 47, Part 15, Subpart B, Class A |
| | Canada | UL Listed, File E107041, CCN PAZX7, Under CAN/CSA C22.2 No. 205, Signal Equipment; Industry Canada, ICES-003 |
| | Europe | CE Mark – Johnson Controls declares that this product is in compliance with the essential requirements and other relevant provisions of the EMC Directive 2004/108/EC. |
| | Australia and New Zealand | RCM Mark, Australia/NZ Emissions Compliant |
| Shipping Weight | | 0.24 lb (0.11 kg) |

| Ompping Weight | | 0.24 ib (0.11 kg) |
|--------------------------------------|---------------------------|---|
| | | NS Series Network Zone Sensor—CO ₂ Models |
| Supply Voltage | | Non-isolated: 20 to 30 VAC (18 to 30 VDC), Class 2 or Safety Extra-Low Voltage (SELV) |
| | | Isolated: 9.8 to 16.5 VDC; 15 VDC nominal (from SA bus) |
| Current Consumption | | Non-isolated: 22 mA average at 24 VAC; 28 mA average at 24 VDC |
| | | Isolated: 5 mA maximum, non-transmitting (from SA bus) |
| Power Consumption | on | Non-isolated: less than 0.7 W average |
| Terminations | | Non-isolated supply: screw terminal block |
| | | SA bus: modular jack or screw terminal block |
| Sensor Addressing | g | DIP switch set from 212 to 219; factory set at 212 |
| Wire Size | | Modular jack: 24 AWG or 26 AWG (0.5 or 0.4 mm diameter) recommended; three twisted pair (six conductors) |
| | | Screw terminal block: 18 to 22 AWG (1.0 to 0.6 mm diameter); 22 AWG (0.6 mm diameter) recommended |
| Communication Ra | ate | Auto-detect: 9.6k, 19.2k, 38.4k, or 76.8k bps |
| CO ₂ Measurement | Range | 0 to 2,000 ppm |
| CO ₂ Sensing Accu | racy | Plus or minus the sum of 40 ppm and 2.0% of the CO ₂ reading at 77°F (25°C) and 978 hPa or an altitude of 1,000 ft/300 m Note: All accuracy specifications reflect the testing of the device using high-grade certified gases. This device is |
| | | intended for an altitude range of 0 ft/0 m to 2,000 ft/600 m above sea level without compensation. |
| | | Temperature dependence of output: -0.35% of the CO ₂ reading per 1.8F°/1C° typical |
| | | Pressure dependence of output: +0.15% of the CO ₂ reading per 1 hPa typical |
| CO ₂ Sensing Reso | lution | 1 ppm |
| CO ₂ Sensing Resp | onse Time | 1 minute (0 to 90%) |
| CO ₂ Sensing Warm-Up Time | | Less than 1 minute; less than 10 minutes for full accuracy |
| CO ₂ Sensing Long | -Term Stability | Less than ±100 ppm over 5 years |
| Mounting | | Surface-mounted or vertical wallbox-mounted: 120 x 80 mm |
| Ambient Condition | IS | Operating: 32 to 104°F (0 to 40°C); 10 to 90% RH, noncondensing; 85°F (29°C) maximum dew point; 700 to 1,200 hPa |
| | | Storage: -40 to 158°F (-40 to 70°C); 0 to 95% RH, noncondensing |
| Compliance | BACnet International | BACnet Testing Laboratories™ (BTL) 135-2004 Listed BACnet Smart Sensor (B-SS) |
| | United States | UL Listed, File E107041 CCN PAZX, Under UL 916, Energy Management Equipment; FCC Compliant to CFR 47, Part 15, Subpart B, Class A |
| | Canada | UL Listed, File E107041, CCN PAZX7, Under CAN/CSA C22.2 No. 205, Signal Equipment; Industry Canada, ICES-003 |
| C€ | Europe | CE Mark – Johnson Controls declares that this product is in compliance with the essential requirements and other relevant provisions of the EMC Directive 2004/108/EC. |
| | Australia and New Zealand | RCM Mark, Australia/NZ Emissions Compliant |
| Shipping Weight | | 0.35 lb (0.16 kg) |



| NS Series Network Zone Sensor—Flush-Mount Temperature Only Models | | |
|---|---------------------------|--|
| Supply Voltage | | 9.8 to 16.5 VDC; 15 VDC Nominal (from SA bus) |
| Current Consumption | | 12 mA maximum (non-transmitting) per flush-mount network sensor |
| Terminations | | Screw terminal block Note: Wire leads are field supplied and are not tinned. |
| Sensor Addressing | g | DIP switch set from 200 to 203; factory set at 203 |
| Wire Size | | 18 to 22 AWG (1.0 to 0.6 mm diameter); 22 AWG (0.6 mm diameter) recommended; 10 ft (304.8 cm) wiring lead Included with the unit |
| Communication Ra | ate | Auto-detect: 9.6k, 19.2k, 38.4k, or 76.8k bps |
| Temperature Meas | urement Range | 32.0°F/0.0°C to 104.0°F/40.0°C |
| Temperature Sensor Type | | Local 1k ohm Platinum Resistance Temperature Detector (RTD); Class A per IEC 60751 |
| Temperature Accu | racy | NS Series Network Zone Sensor: ±1.0F°/±0.6C° |
| | | Temperature Element Only: 0.35F° at 70°F (0.2C° at 21°C) |
| Ambient Condition | ıs | Operating: 32 to 104°F (0 to 40°C); 10 to 90% RH, noncondensing; 85°F (29°C) Maximum Dew Point |
| | | Storage: -40 to 158°F (-40 to 70°C); 5 to 95% RH, noncondensing |
| Compliance | BACnet International | BACnet Testing Laboratories™ (BTL) 135-2004 Listed BACnet Smart Sensor (B-SS) |
| | United States | UL Listed, File E107041, CCN PAZX, Under UL 916, Energy Management Equipment; FCC Compliant to CFR 47, Part 15, Subpart B, Class A |
| | Canada | UL Listed, File E107041, CCN PAZX7, Under CAN/CSA C22.2 No. 205, Signal Equipment; Industry Canada, ICES- 003 |
| CE | Europe | CE Mark – Johnson Controls declares that this product is in compliance with the essential requirements and other relevant provisions of the EMC Directive 2004/108/EC. |
| | Australia and New Zealand | RCM Mark, Australia/NZ Emissions Compliant |
| Shipping Weight | | 0.25 lb (0.11 kg) |

| | | NS Series Network Discharge Air Sensors |
|-------------------------|---------------------------|--|
| 0 1 1/1/1 | | • |
| Supply Voltage | | 9.8 to 16.5 VDC; 15 VDC nominal |
| Current Consump | tion | 12 mA maximum (non-transmitting) per discharge air sensor |
| Terminations | | Four color-coded wiring leads, stripped and tinned; factory-installed at the discharge air sensor screw terminal block |
| Sensor Addressin | g | DIP switch set from 204 to 211; factory set at 204 |
| Wire Size | | 18 to 22 AWG (1.0 to 0.6 mm diameter); 22 AWG (0.6 mm diameter) recommended; 10 ft (305 cm) wiring lead included with the unit |
| Communication Rate | | Auto-detect: 9.6k, 19.2k, 38.4k, or 76.8k bps |
| Mounting | | Duct-mounted: 4 or 8 in. (102 or 203 mm) temperature probe length |
| Temperature Meas | surement Range | 14°F/-10°C to 140°F/60°C |
| Temperature Sensor Type | | Local 1k ohm Platinum Resistance Temperature Detector (RTD); Class A per IEC 60751 |
| Temperature Accu | ıracy | NS Series Network Discharge Air Sensor: ±1.0F°/±0.6C° |
| | | Temperature element only: 0.35F° at 70°F (0.2C° at 21°C) |
| Ambient Condition | ns | Operating: 14 to 140°F (-10 to 60°C); 10 to 90% RH, noncondensing; 85°F (29°C) Maximum Dew Point |
| | | Storage: -40 to 158°F (-40 to 70°C); 5 to 95% RH, noncondensing |
| Compliance | BACnet International | BACnet Testing Laboratories™ (BTL) 135-2004 Listed BACnet Smart Sensor (B-SS) |
| C€ | United States | UL Listed, File E107041, CCN PAZX, Under UL 916, Energy Management Equipment; FCC Compliant to CFR 47, Part 15, Subpart B, Class A |
| | Canada | UL Listed, File E107041, CCN PAZX7, Under CAN/CSA C22.2 No. 205, Signal Equipment; Industry Canada, ICES-003 |
| | Europe | CE Mark – Johnson Controls declares that this product is in compliance with the essential requirements and other relevant provisions of the EMC Directive 2004/108/EC. |
| | Australia and New Zealand | RCM Mark, Australia/NZ Emissions Compliant |
| Shipping Weight | | NS-DTN7043-x: 1.15 lb (0.52 kg) |
| | | NS-DTN7083-x: 1.17 lb (0.53 kg) |

| NS Series Network Sensors with Fault Code Capability | | |
|--|---|--|
| Supply Voltage | 9.8 to 16.5 VDC; 15 VDC nominal (from SA bus) | |
| Current Consumption | 21 mA maximum, non-transmitting (from SA bus) | |
| Network Sensor Addressing | DIP switch set from 200 to 203; factory set at 203 | |
| Terminations | Screw terminal block | |
| Screw Terminal Wire Size | 18 to 22 AWG (1.0 to 6.0 mm Diameter); 22 AWG (0.6 mm diameter) recommended | |



| NS Series Network Sensors with Fault Code Capability | | |
|--|------------------------------|--|
| Communication Rate | | Auto-detect: 9.6k, 19.2k, 38.4k, or 76.8k bps |
| Temperature Measurement Range | | 32.0°F/0.0°C to 104.0°F/40.0°C |
| Temperature Sensor Type | | Local Platinum Resistance Temperature Detector (RTD) |
| Temperature Resolution | | ±0.5F°/±0.5C° |
| Temperature Accuracy | NS Series Network Sensor | ±1.0F°/±0.6C° |
| | Temperature Element Only | 0.35F° at 70°F (0.2C° at 21°C) |
| Time Constant | | 10 minutes nominal at 10 fpm airflow |
| Default Tempera Adjustment Ran | | 50.0°F/10.0°C to 86.0°F/30.0°C in 0.5° increments |
| Ambient Conditions | Operating | 32 to 104°F (0 to 40°C); 10 to 90% RH, noncondensing; 85°F (29°C) maximum dew point |
| | Storage | -4 to 140°F (-20 to 60°C); 5 to 95% RH, noncondensing |
| Compliance | United States | UL Listed, File E107041, CCN PAZX, Under UL 916, Energy Management Equipment |
| | | FCC Compliant to CFR 47, Part 15, Subpart B, Class A |
| | Canada | UL Listed, File E107041, CCN PAZX7, Under CAN/CSA C22.2 No. 205, Signal Equipment |
| | | Industry Canada, ICES-003 |
| C€ | Europe | CE Mark – Johnson Controls declares that this product is in compliance with the essential requirements and other relevant provisions of the EMC Directive 2004/108/EC. |
| | Australia and New Zealand | RCM Mark, Australia/NZ Emissions Compliant |
| Dimensions (Height x Width x Depth) | | NS-ATBF703-x: 3-5/32 x 3-5/32 x 1-3/8 in. (80 x 80 x 35 mm) NS-BTB7F03-x: 4-23/32 x 3-5/32 x 1-3/8 in. (120 x 80 x 35 mm) |
| Shipping Weight | | 0.25 lb (0.11 kg) |